

**ARTICLE V.  
INFILTRATION AND INFLOW**

**SECTION 5.01: Prohibition of Infiltration and Inflow**

Each Developer, property owners and subsequent customers connected to the Authority System are prohibited from introducing extraneous flows that are not directly derived from a legal connection to the sewer system.

**SECTION 5.02: Illegal Connections**

The discharge of roof, storm, surface, or building foundation water or drainage into the sewer is expressly prohibited. Floor drains in basements subject to groundwater infiltration or flooding must also be removed, permanently sealed, or otherwise not connected to the Building Sewer.

**SECTION 5.03: Inspection and Discharge Regulations**

The Authority shall perform the following:

At the time of the inspection of the Building Sewer, and from time to time as determined by the Authority, Authority representatives shall have the right to inspect the facilities at the observation port to determine whether the facilities connected to the Sewer System are in conformance with the applicable Rates, Rules and Regulations.

All water contaminated by use must be discharged into the sewer including water from sinks and washing machines. Illegal connections must be immediately removed from the system.